

## **Safety and User Manual**

Usage and Electrical Safety.....	1
Cleaning and Maintenance.....	1
Environmental Conditions and Storage.....	2
Safety for Children and Pets.....	2
Environmental and Disposal Guidelines.....	2
Warranty and Liability Limitations.....	2

### **Usage and Electrical Safety**

- Always disconnect the power cable before cleaning, maintenance, or inspection.
- Do not use the device if the USB cable, plug, or LED strip is visibly damaged (e.g., cracks, exposed wires, etc.).
- Keep the device in a dry and secure place, away from high temperatures, fire, or moisture.
- Do not cover the plug or USB connection, and do not bend or pull the cable forcefully.
- Do not use a damaged cable. Covering a damaged cable with tape is not a safe or permanent solution.
- If the device becomes unusually hot, emits smoke, produces an odor, or sparks, immediately turn it off and disconnect the USB connection.
- Do not modify the device or cable (e.g., opening or rewiring). Unauthorized modifications or repairs will void the warranty and may create hazards.
- Remember that what is safe for you may be dangerous for others. Ensure that all individuals who must use electrical devices know how to use them correctly and safely.

### **Cleaning and Maintenance**

- Disconnect the device from the power supply (unplug USB) before cleaning.
- Use a soft, dry, or slightly damp cloth (with water or a mild, non-solvent detergent) for cleaning. Do not use aggressive cleaning agents, solvents, chlorine, or abrasive materials.
- Do not spray liquids directly onto the device; always apply the cleaning solution to the cloth.
- Ensure the device is completely dry before reconnecting.

## **Environmental Conditions and Storage**

- Store in a dry and well-ventilated location.
- Avoid direct sunlight, heat sources (radiators, stoves), and open flames.
- Prolonged exposure to extreme temperatures (e.g., below 0 °C or above 40 °C) is not recommended.
- Keep away from sharp objects and areas under pressure. Do not sit or walk on the device.

## **Safety for Children and Pets**

- This device is not a toy.
- Small parts or detachable components may pose a risk of choking or accidental ingestion.

## **Environmental and Disposal Guidelines**

- Electronic waste (E-waste) must be disposed of in accordance with local regulations (EU: WEEE). At the end of its service life, return the device to a collection or take-back point for environmentally responsible disposal.
- Packaging and accessories: separate plastic, paper, and other materials according to local waste management rules.

## **Warranty and Liability Limitations**

The manufacturer shall not be held liable for damages or losses resulting from: use inconsistent with these instructions, intentional modification of the device, use with an unsuitable power source, negligent handling, or unauthorized repairs.

This manual does not replace applicable local laws and regulations. If you require more detailed legal wording, consult a qualified legal professional.